



KULLANIM TALİMATI

*USAGE
INSTRUCTIONS*

KULLANIM VE BAKIM TALİMATI



Fırın



Mikrodalga



Gazlı Ocak



Elektrikli
Ocak



Bulaşık
Makinesi



Ilık Su
Kullanınız.



Elde
Yıkayınız.

- Ürünleri suda bekletmeyiniz.
- Ürünlerinizi bulaşık makinesinde yıkamayınız.
- Ilık suyla elde yıkayınız.
- Ürünlerin 15 günde bir zeytinyağlayınız.
- Ürünlerinizin bakımını 3 ayda bir yaptırınız.
- Her kullanımdan sonra ya da haftada bir defa sirke, limon, kaya tuzuyla ovalayarak bakterilerden kurtulabilirsiniz.
- Ürünlerinizi ızgara üzerinde bekletmeyiniz.
- Ürünleri yıkadıktan sonra dik olacak şekilde, yan yana dizerek kurutmalısınız. Islak ürünler üst üste konulmamalıdır.

USE & CARE INSTRUCTIONS



Oven



Microwave



Gas
Cooker



Electric
Stove



Dishwasher



Warm
Water



Wash it in
hand

- *Do not keep your products in water.*
- *Do not wash your products in the dishwasher.*
- *Wash the products by hand with warm water.*
- *Apply olive oil every 15 days.*
- *Make your products maintenance every 3 months.*
- *You can get rid of bacteria by rubbing it with vinegar, lemon, rock salt after each use or once a week.*
- *Do not keep your products on the grill.*
- *After washing the products, you should dry them vertically, lining them side by side. Wet products should not be stacked on top of each other.*

